

Wireless LANC Controller Instructions



Step 1: Connect the HDMI control cable to the control port on the Digital Video Recorder.



Step 2: Connect the other end of the LANC control cable to the LANC receiver.



Step 3: The wireless controller is now setup. The DVR can be controlled either by the key chain clicker or by the switch located on the LANC receiver. If the key chain clicker is not working properly make sure the frequency keys match. Slide the key door up on the LANC receiver and pull up the "wehshung" sticker on the key chain clicker. Inside will be 10 key switches. Ensure that both sets on the clicker and receiver match. If not use a small flat head screw driver to make the proper correction.



Email us at support@raceoptics.com for questions.